

OPERATING YOUR IC BUS



MAINTENANCE TABLE - HIGH VOLTAGE COMPONENTS

The following table references the high voltage components requiring maintenance.

The remaining chassis maintenance items follow the current diesel service intervals and procedures.

For a full list of vehicle maintenance items, please refer to the Operation and Maintenance Manual.

Maintenance Item	Interval
High Voltage Air Compressor Filter	10,000 miles (16,000 km) / 400 hours / 1 Year
Air Dryer Filter	AD-9 Model: 250,000 miles (400,000 km) / 2 Years Other Models: 125,000 miles (200,000 km) / 1 Year
Electronics Cooling System - Change and Refill	150,000 miles (240,000 km) / 5 Years
BTMS Coolant System - Change and Refill	150,000 miles (240,000 km) / 5 Years
Cabin Heater Coolant System - Change and Refill	150,000 miles (240,000 km) / 5 Years
Power Steering - Change and Refill	100,000 miles (160,000 km)
Rear Axle With Petroleum - Change and Refill	60,000 miles (96,000 km) / 1 Year
Rear Axle With Synthetic - Change and Refill	180,000 miles (288,000 km) / 3 years
A complete list of Pre/Post check items and other chassis related maintenance intervals can be found in the Operation and Maintenance Manual.	

